

DESIG	A .	DRAWN BY	DART AEROSPA HAWKESBURY, ONTARIO,	
CHECK	(ED	APPROVED///	DRAWING NO.	REV. A
	V.V.	THE THE	DSI 9325	SHEET 1 OF 1
DATE	w / <sub>0</sub>		TITLE	SCALE
06.03.27			SPACER ADDITION	NTS
Α		06.03.27	NEW ISSUE	

## DART SERVICE INSTRUCTION

TO AMEND INSTALLATION DRAWING D204-618 REV. B

(REF. CANADIAN STC: SH91-40, FAA STC: SR00505NY)

FOR INSTALLATION OF D204-618-011/-012, IT IS NECESSARY TO ADD (2) D2022-101 SPACERS PER KIT TO INSTALL THE STEP. CONSEQUENTLY, LONGER BOLTS ARE NEEDED AS PER DETAIL A BELOW TO ALLOW THE INSTALLATION OF THE SPACERS. THIS CHANGE IS REQUIRED BECAUSE THE TUBE SECTION OF THE STRUTS INTERFERE WITH EACH OTHER BEFORE THE TABS CONTACT THE DOOR PLATE BRACKET.

REPLACE: QTY (1) AN4-5A BOLT WITH: QTY (1) AN4-11A BOLT

ADD: QTY (2) D2022-101 SPACERS

